

# Stage

<u>Proscenium opening:</u>	25' Wide - 9' High
<u>Apron:</u> Front of Curtain	5½' x 25'
<u>Stage:</u> From proscenium opening to Cyclorama	22'
Wing space stage right	11' x 22'
Wing space stage left	8' x 22'
Ground to Lighting Rig	12'.6"
Auditorium	73' x 33'
Seating	350

# Lighting

Lightmaster XLS ZERO 88  
24 Dimmer Channels 48 Circuits

## Front of House

### 16 Circuits

4	x	650w	Prelude	16/30	
4	x	650w	Strand	28/40	
2	x	650w	Strand	15/32	
2	x	1000w	Starlette		pc ctt
2	x	1000w	Fresnel	(wash)	
			Spare Channels		

## Batten 1

12	x	650 w	Strand quartets
----	---	-------	-----------------

## Batten 2

3	x	1000w	Parcans
1	x	600w	Strand quartets
3	x	500w	Pattern 23 baby mirror spots

## Cyclorama

1	x	4:500w	Coda
2	x	1:500w	Coda
2	x	1000w	Parcans
2	x	500w	Floods
1	x	2:500w	Halogen floods on stand
4	x		Spare Stage Circuits

# Sound

## Behringer Control Board

Eurorack MX 1804 x 14 Channel

Pioneer Six Disk Player

Sony 2 Deck Tape Record/Player

Sony mini Disk Player

Amplifier: Q4 Audio PTH7

H7 2 x 700w Professional Power Amplifier